1
2
3
4
5
6
7
8
9
SEVERIN
2000 IONIC

GB

Hair dryer

Dear Customer
Before using the appliance, the user should read the following instructions carefully.

Connection to the mains supply
The hair dryer should only be connected to a socket installed in accordance with the regulations.
Make sure that the supply voltage corresponds with the voltage marked on the rating label of the hair dryer.
This product complies with all binding CE labelling directives.

Familiarisation
1. Indicator light
2. Air outlet opening
3. Professional styling nozzle
4. Cool function
5. Air temperature control
6. Air intake openings
7. Air flow control
8. Hanging loop
9. Power cord with plug

Important safety instructions

- **Caution:** do not use the appliance in the vicinity of a bath, shower or swimming-pool, over a washbasin filled with water or near any other receptacle containing water.

  Protect the appliance from moisture and splashing water and do not operate it with wet hands.
- In the vicinity of any water source, there is a risk even when the appliance is switched off. Therefore, always remove the plug from the wall socket after use, especially if the appliance is being used in a bathroom.
  For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.
- Electric heating appliances operate at very high temperatures. Do not touch any part of the appliance except the grip. Otherwise there is a real risk of burning.
- Do not use the appliance on synthetic hair-pieces or wigs, as the heat emitted might cause damage to the synthetic fibres.
- Make sure the air intake and outlet openings are not blocked (e.g. by fingers or hair), and that no fluff or fibre particles are allowed to accumulate in the air intake.
  A blockage in the air-flow system may cause the integral thermal safety cut-out to switch off the appliance. Should this occur, immediately disconnect the appliance from the mains power and allow sufficient time for it to cool down before the blockage is removed and the appliance is switched on again.
- Every time the appliance is used, the main body including the power cord as well as any attachment fitted should be checked thoroughly for any defects. Should the appliance, for instance, have been dropped onto a hard surface, it must no longer be used: even invisible damage may have adverse effects on the operational safety of the appliance.
- To prevent damage to the power cord,
  - do not bend or kink the cable, especially where it leaves the housing,
  - do not pull on the cord,
  - do not coil the power cord around the appliance.
- Do not leave the appliance unattended while in use.
- **Always switch off and remove the plug from the wall socket after use, as well as**
  - **in cases of malfunction, and**
  - **during cleaning.**
- When removing the plug from the wall socket, never pull on the power cord; always grip the plug itself.

- Do not place the appliance on any surfaces sensitive to heat during or immediately after use.
- This appliance is not intended for use by any person (including children) with reduced physical, sensory or mental capabilities, or lacking experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- No responsibility will be accepted if damage results from improper use, or if these instructions are not complied with.
- This appliance is intended for domestic use only and not for commercial applications.
- In order to comply with safety regulations and to avoid hazards, repairs of electrical appliances must be carried out by qualified personnel, including the replacement of the power cord. If repairs are needed, please send the appliance to one of our customer service departments. The addresses can be found in the appendix to this manual.

The IONIC function

The IONIC function facilitates gentle, easy hair styling by preventing a static charge in the hair. It uses the build-up of a negative 'ion-cloud' to prevent 'flyaway' hair caused by a positive charge.
The IONIC function is enabled while the indicator light is on. With the cool function activated, or with the air temperature and air flow controls set to position 1, the IONIC function is automatically disabled.

Styling nozzle

The styling nozzle can be fitted to the air outlet to facilitate shaping the hair during blow drying.

Air-flow and temperature controls

By using different combinations of the air-flow and temperature controls, various settings are possible when drying the hair.
The air-flow control regulates the air-flow intensity, while the temperature control regulates the heat of the air-flow.
With the air-flow control set to the '**0**'-position, the hair-dryer is switched off.

Cool function

The cool function can be used at any time during the drying process. It will supply cooler air, which helps firming and shaping the hair.

Operation

Connect the hair dryer to a suitable wall socket and select the desired power setting with the switches integrated in the handle.

Cleaning and care

- Before cleaning the hair dryer, remove the plug from the wall socket and let the appliance cool down completely.
- To avoid the risk of electric shock, do not clean the hair dryer with water nor immerse it in water.

– If necessary, the housing of the hair dryer may be wiped with a dry lint-free cloth.
– Always check the air intake openings for accumulated lint particles or hair and - if necessary - remove any found.
To facilitate cleaning, the grille on the air intake can be removed by turning it anti-clockwise and then lifting it off. After cleaning, replace the grille and lock it by turning clockwise.

Disposal

Do not dispose of old or defective appliances in domestic garbage; this should only be done through public collection points.

Guarantee

This product is guaranteed against defects in materials and workmanship for a period of two years from the date of purchase. Under this guarantee the manufacturer undertakes

to repair or replace any parts found to be defective, providing the product is returned to one of our authorised service centres. This guarantee is only valid if the appliance has been used in accordance with the instructions, and provided that it has not been modified, repaired or interfered with by any unauthorised person, or damaged through misuse.

This guarantee naturally does not cover wear and tear, nor breakables such as glass and ceramic items, bulbs etc. If the product fails to operate and needs to be returned, pack it carefully, enclosing your name and address and the reason for return. If within the guarantee period, please also provide the guarantee card and proof of purchase.